



Constant Current Power Supplier

Constant current power suppliers can be used for any IEPE sensors with bias voltage between 7~13 V. All BW

constant current power suppliers have pre-set the current level at 2 mA . Specify customer current level (2 to 10 mA), when the order is placed

61000 Single Channel Constant Power Supplier

- * Compact design
- * Powered by 9V Battery or external 7 ~ 30 V
- * Working condition indicator

61000 Series Multiple Channel Constant Power Supplier

- * Selection of 4 ~ 16 channels constant power supplier with standard case
- * Powered by AC (220 VAC) or DC (18 ~ 30 VDC) or battery
- * Output signal with gain of x1 and x10, and working condition indicator

61001 On-Line Constant Current Power Supplier

- * Simple, reliable and low cost design
- * External power of 18 ~ 30 VDC



Model	Unit	61000	61001	61011	61012	61015	61016
Number of Channel		1	1	4	8	8	4
Output Gain		x1	x1	x1,x10	x1,x10	x1,x10	x1
Power Output Voltage	V	24					
Output Constant Current	mA	2~10(According to the demand of customer)					
Frequency Range	Hz	0.025~100k					
Working Condition Indicator		Yse / LED	Non	Yse / LED	Yse / LED	Yse / LED	Non
Noise Threshold	μVrms	<10					
Battery Power		9Vx1	Non	9Vx3x2	9Vx3x3	9Vx3x3	Non
External Power	V	DC7~30	DC18~30	220V/DC18~30	220V/DC18~30	220V/DC18~30	DC18~30
Input / Output Connector		BNC					
External Dimension	mm	91x61x27	φ15x50	290x200x50	483x250x50	290x210x60	150x90x55
Weight	gram	32	30	2800	4850	3200	650